

# Cylinder Valves

808107



## OPD Valves

Part Number	Dip Tube Length	Fits Cylinder	Connection Type	Manufacturer
<b>809890</b>	3.0"	5# Steel	QCCI	Cavagna
<b>808109</b>	4.8"	30# Steel		
<b>808110</b>	6.5"	40# Steel		
<b>808142</b>	3.6"	10# Steel		
<b>808107</b>	4.0"	20# Steel		
<b>V21464<sup>1</sup></b>	4.0"	20# Steel	QCCI	Manchester
<b>PV3004A</b>	5.8	30# Aluminum		Emerald Isle
<b>PV4004A</b>	7.0"	40# Aluminum		
<b>ME392P</b>	1 5/16" FACME sealing brass cap protects threads during refurbishment			Marshall Excelsior
<b>94QCI</b>	QCCI plastic valve cover cap pre-bagged quantity-25			

(1) Sureflame® Float valve and gauge dial, replacement dial part no V21462

## CYLINDER VALVES

805016



## Cylinder Valves

Part Number	Description
<b>802146</b>	FPOL service valve, No relief, 3/4" MPT, 1.5 GPM excess flow
<b>805016</b>	100# Cylinder Valve with Spitter, 375 psig Relief
<b>806032</b>	Heavy Duty, Up to 200# Cylinder Valve, with Spitter
<b>802146</b>	FPOL service valve, No relief, 3/4" MPT, no dip tube
<b>3250ALG11.6</b>	100# Cylinder Valve with Spitter, 375 psig Relief
<b>3250ALM11.6</b>	100# Cylinder valve for liquid with excess flow check and dip tube
<b>3250ALG711</b>	420# Cylinder Service Valve, 11" Driptube, No Relief
<b>3250BC-312</b>	RV Valve, 312 psig Relief, FPOL x 3/4" MNPT
<b>3329BDB</b>	FPOL service valve, No relief, 3/4" MPT, no dip tube
<b>9107K8A</b>	100# Cylinder Withdrawal Valve, Male CGA 555, Excess Flow
<b>9103D11.6</b>	100# Cylinder Valve 11.6" Driptube 375 psig Relief

Note: 2 lb. to 100 lb. cylinders for vapor service are required to have a fixed maximum liquid level gauge (spitter). The liquid level gauge can be separate or part of the cylinder valve.



3250BC-312

Bergquist



bergquistinc.com | 800 537 7518

# Cylinder Filling Valve, Cylinder Valve Repair Kits

**Type N201** fills DOT cylinders by weight and stops the gas supply when specified fill weight is reached. Operated by air pressure, it is designed for beam type scales and requires no electrical or mechanical power.

The assembly comes completely piped up and includes special parts that allow the slide weight on the scale to move to zero. A red button appears in the indicator on top of the N201 each time a cylinder is filled to the desired weight.



## Cylinder Filling Valve

Part Number	Description
<b>N201</b>	Valve Complete
<b>N201 Repair Kit</b>	Basic repair kit for N201 Valve
<b>N201 Stem Kit</b>	Includes (IF9450, IF9451, 20B938, II1391 & 2-1H2622)

## Fisher Valve Repair Parts

Valve Number Description	B600H, C600H, B659, B650H, L677A	B660, B661	L196, L195
Handwheel	T12069	T12069	T12109
Screw	T10873	T10873	T10873
Complete bonnet stem, seat & O-ring	T13184	---	---
*Seat assembly	T13182	T10869	T10869
*O-ring	T12945	T12946	T12946

N201



bergquistinc.com | 800 537 7518

## Sherwood Valve Repair Parts

Valve Number Description	3329, 2030C/CP, 2033, 1445C	2035A/AP, 3250A/ALM, 1425B, 1426B, 1445B, 1446B, 1427B	3359AS, 3359ASW	2341	3329BDB
Handwheel	-	-	-	1901	-
LH Bonnet, Stem, Seat ass'y. & O-Ring	3329-13LHK	3329-13LHK	3250-8LHK	-	6775-60K
Dual Bonnet	-	-	-	-	3429-100K

## Miscellaneous Valve Repair Parts

Valve Number Description	1477, 2594, 3100, 7100, 6477, 2593	8100	901, 903, 6533D, 6543D, 8555S	9101C/D, 6532A, 6533A, 6542A, 6543A, 7556V, 8593A, G8475, 8555D/DL	8547W	6532, 6533R, 6542R, 6543R, 7556R, G8475R, 8555R, 8593R, 9101R
Handwheel	9107-31	9107-31	9107-31	---	9107-31	903-31
Diaphragm, bonnet & stem ass'y.	---	8100-50	---	---	---	---
Diaphragm ass'y.	3100-80B	---	---	---	---	---
Bonnet, valve stem, O-ring ass'y.	---	8100-50	---	---	---	---
Conversion kit	3100-81K	---	---	---	---	---
Bonnet ass'y., handwheel screw & washer	---	---	903-50 (L) 903-51 (S)	19100-50B	---	19104-50
Multi bonnet conversion kit	---	---	---	19104-50	---	---
Upper packing nut for multi-bonnet	---	---	---	---	---	19104-80