


OHIO	800 537 7518
INDIANA	800 662 3252
MISSOURI	800 821 3878
KENTUCKY	800 448 9504
MINNESOTA	800 328 6291
FAX	800 383 4664

## Tubing Bender

Part No.	O.D. Tube Size	Length
102-F-04	1/4"	10"
102-F-06	3/8"	10"
102-F-08	1/2"	12"
102-F-10	5/8"	12"



Note: For bending soft tubing to any shape without collapsing walls. Special spring steel, nickel finish. End belled for quick spring removal.

## Serviceman's Friend

Part No.	Description
TL051	Serviceman's friend



Use with flow meter and other applications. One end has 1/8" pipe thread, 1/4" pipe thread and special 5/16" x 32 thread. Opposite end has regular hose fitting & 1/8" straight pipe thread. Hose can be used on either end.

## Safety Anvil

Part No.	Description
TL074	Safety anvil



Orifice caps can be held in this anvil while reaming size for the adaptors. This tool is used to install M1100-72.

## Handpiece

Part No.	Description
TL061	Handpiece

Fits large reamer TL070



## Gauging Drill Set

Part Number	Description
G4080	Drill kit #40 to #80 & #90 reamer
G1939	Gauging drill kit #19-39



## Replacement Drills

Part Number	Description
GD19 - GD80 (Each)	Individual Drills #19 to #80
G3015	#90 without handle
G3020	#90 with handle

